

Quick Start Guide

GV-GPTZ4810



Before attempting to connect or operate this product,
please read these instructions carefully and save this manual for future use.

GPTZ-QG-A



© 2024 GeoVision, Inc. All rights reserved.

Under the copyright laws, this manual may not be copied, in whole or in part, without the written consent of GeoVision.

Every effort has been made to ensure that the information in this manual is accurate. GeoVision, Inc. makes no expressed or implied warranty of any kind and assumes no responsibility for errors or omissions. No liability is assumed for incidental or consequential damages arising from the use of the information or products contained herein. Features and specifications are subject to change without notice.

GeoVision, Inc.
9F, No. 246, Sec. 1, Neihu Rd.,
Neihu District, Taipei, Taiwan
Tel: +886-2-8797-8377
Fax: +886-2-8797-8335
<http://www.geovision.com.tw>

Trademarks used in this manual: *GeoVision*, the *GeoVision* logo and *GV* series products are trademarks of GeoVision, Inc. *Windows* is the registered trademark of Microsoft Corporation.

December 2024

Scan the following QR codes for product warranty and technical support policy:



[Warranty]



[Technical Support Policy]

Warning and Caution


- If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the camera yourself. (We shall not be responsible for any problems caused by unauthorized repair or maintenance.)
- Keep away from liquid while use.
- In the use of the product, you must be strict compliance with the electrical safety regulations of the nation and region. When the product is mounted on wall, the device shall be firmly fixed.
- Do not use camera beyond specified voltage range.
- Do not drop the camera or subject it to physical shock.
- Avoid touching the camera lens.
- If cleaning is necessary, please use clean cloth to wipe it gently.
- Do not aim the camera at the sun or extra bright place.
- Do not place the camera in extremely hot, cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- To avoid heat accumulation, good ventilation is required for operating environment.

Contents

1. Overview	1
1.1 Camera Overview	1
1.2 Cable Connection	2
2. Installation	4
3. Accessing the Network Camera	6
3.1 Looking Up the Dynamic IP Address	6
3.2 Configuring the IP Address	8
4. The Web Interface	10
5. Upgrading System Firmware	12
6. Restoring to Factory Default	13

1. Overview

1.1 Camera Overview




1	Ethernet connector (PoE)	6	Microphone
2	MIC-Audio input (3.5 mm)	7	Ground
3	HP-Audio output (3.5 mm)	8	Memory card slot
4	Alarm input / output	9	Reset
5	DC 12V power jack		


Note:

1. The product must be grounded to reduce the risk of electric shock.
2. Press and hold the reset button for more than 5 seconds to restore to the factory default setting.

1.2 Cable Connection




Connecting Network Cable



Note: If the RJ-45 connector of the network cable has a jacket and cannot be threaded through the kit, remove the jacket. If the jacket cannot be removed, cut off the connector and install an RJ 45 connector without the jacket.

Connecting Alarm Input / Output

The max. load of alarm output: DC 30V, 1A.




2. Installation

Make sure that the wall is strong enough to the weight of the camera and the camera is powered off during installation.


Note: The recommended installation height is 3 ~ 5 m for smart tracking.

Memory Card Installation

1. Loosen the two screws of the cover and then remove the cover.




2. Insert a micro SD card and then install the cover back.




Ceiling Mounting


1. Use the four screws provided to install the adapter to the ceiling.




2. Align the three screw holes of the adapter with the screws of the mounting base.



3. Put the three screws into the screw holes. After that, turn the camera clockwise to secure it.



4. Adjust the camera position and then tighten the lock screw on the side. Note that the microphone should face the monitoring scene.




Note: Do not use an electric screwdriver to secure. Using an electric screwdriver may result in overtightening. The three M3 screws are designed to latch onto the adaptor without the need for fastening.


3. Accessing the Network Camera

3.1 Looking Up the Dynamic IP Address


By default, when the camera is connected to a LAN with a DHCP server, it is automatically allocated a dynamic IP address. Follow the steps below to look up its IP address, and then use that address to access its Web interface.

Note: By default, the Administrator's username is **admin** and cannot be modified.

1. Make sure the PC used to configure the IP address is under the same LAN as the camera. Download and install **GV-IP Device Utility** from the company [website](#).
2. On the GV-IP Utility window, click the  button to search for IP devices connected to the same LAN. To sort, click the **Name** or **Mac Address** column.
3. Find the camera with its Mac Address, and click on its IP address.



4. For first-time users, you are requested to create a password.



5. Type a new password and click **OK**.
6. Click on its IP address on the Utility window again and select **Web Page** to access its Web interface.
7. Type the set password on the login page and click **Login**.

Note: To change the password using GV-IP Device Utility, click on the camera's IP address, and select **Configure > Change Password**. Alternatively, you can change the password on the camera's Web interface by clicking **Config > Security > User**; see "Modify User" in [3.7.1 User Configuration](#) in the user's manual.

3.2 Configuring the IP Address

If the camera is connected to a LAN without a DHCP server, the default IP address will be **192.168.0.10**. To avoid IP conflict with other GV-IP devices on the same LAN, configure an IP address as described below.

1. Open your Web browser, and type the default IP address **192.168.0.10**.
2. Type the default username **admin** and a password. Click **Login**.
3. Go to **Config > Network > TCP/IP** to set the IP address.
4. Select **Use the following IP address** and enter the static IP address and other parameters.


IPv4	IPv6	PPPoE Config	IP Change Notification Config
<input type="radio"/> Obtain an IP address automatically			
<input checked="" type="radio"/> Use the following IP address			
IP Address	<input type="text" value="192.168.226.201"/>	<input type="button" value="Test"/>	
Subnet Mask	<input type="text" value="255.255.255.0"/>		
Gateway	<input type="text" value="192.168.226.1"/>		
Preferred DNS Server	<input type="text" value="210.21.196.6"/>		
Alternate DNS Server	<input type="text" value="8.8.8.8"/>		























5. Click **Save**. The camera can now be accessed with the configured IP address.



4. The Web Interface


Once you log in the Web interface, you will see the live view as shown below.

























Note: The main stream over 1080P, two-way audio, local recording, and the preview mode switch (real-time / balanced / fluent mode) are only supported in IE mode in Microsoft Edge.







Icon	Description	Icon	Description
	Original size		Rule information display
	Fit correct scale		Color abnormal indicator
	Auto (fill the window)		Abnormal clarity indicator
	Full screen		Scene change indicator
	Start/stop live view		Line crossing indicator
	Start/stop two-way audio		Sensor alarm indicator
	Enable/disable audio		Intrusion indicator
	Snapshot		Motion alarm indicator
	Start/stop local recording		Region entrance indicator
	Zoom in		Region exiting indicator
	Zoom out		SD card recording indicator

Icon	Description	Icon	Description
	PTZ control		
	Move the cursor to view the live image in all direction after you click this button. Additionally, hold and drag the left mouse button to zoom in the live image.		

Click  to show PTZ control panel. In the live view interface, you can view the image from every direction by controlling PTZ panel. The descriptions of the control panel are as follows:

Icon	Description	Icon	Description
	Move upper left direction		Move upper right direction
	Move up		Stop movement
	Move left		Move right
	Move lower left direction		Move lower right direction
	Move upper left direction		Speed adjustment
	Zoom out		Zoom in
	Focus -		Focus +
	Iris -		Iris +
	Not functional		Not functional
	Light		Not functional
	Not functional		Preset
	Cruise		Trace

Select preset and click  to call the preset. Select and set the preset and then click  to save the position of the preset. Select the set preset and click  to delete it. Select cruise and click  to start cruise.


For detailed information, see 2. *Live View* in the user's manual.

5. Upgrading System Firmware

GeoVision periodically releases updated firmware on the company [website](#). To load the new firmware into the camera, follow the instructions below.

Using Camera's Web Interface

1. On the Web interface, click **Config > Maintenance > Upgrade**.



Config Home ▶ Maintenance ▶ Upgrade

⚠ Downgrading from the current version to a previous version is not allowed.
Do not disconnect power during the upgrade.


Local upgrade


Path

2. Click **Browse** to locate the firmware file saved at your local computer.
3. Click **Upgrade** to start upgrading the firmware.
4. After upgrading, the camera will restart automatically.


Using GV-IP Device Utility

1. On the GV-IP Utility window, find the camera with its Mac Address, click on its IP address, and select **Configure**. The login credentials are requested.



Name	Mac Address	IP Address	Firmware Version	NOTE
1.  GV-GPTZ4810	0013E224CA9D	192.168.20.107	v1.00_2024-10-12	GV-GPTZ4810

2. Click the **Firmware Upgrade** tab, click the **Browse** button to locate the firmware file saved at your local computer.



The screenshot shows a web interface window with the following elements:

- Mac Address: 0013E224CAAB
- IP Address: 192.168.4.154
- User Login section with User Name: admin and Password: [masked]
- Navigation tabs: Set IP Address, **Firmware Upgrade** (highlighted with a red box), Change Password, Export, Import, Other settings
- File selection area with a text input field containing "----" and a "Browse..." button.
- Checkbox: Upgrade all devices
- Buttons: Upgrade, Cancel

3. Click the **Upgrade** button to start upgrading the firmware.
4. After upgrading, the camera will restart automatically.

6. Restoring to Factory Default


If for any reason the camera is not responding correctly, you can restore the camera back to its factory default settings using the Web interface or the Reset Button.

On the Camera

1. Find the **Reset** button on the camera (see *1.1 Overview* in the Quick Start Guide).
2. Press and hold the button for more than 3 seconds to restore to factory default settings.

On the Web Interface

1. On the Web interface, click **Config > Maintenance > Backup and Restore**.
2. Click the **Load Default** button to restore all system settings to factory default. Optionally, you can select and remain Image settings.



The screenshot shows a web interface for 'Backup and Restore' settings. At the top, there is a breadcrumb trail: 'Config Home > Maintenance > Backup and Restore'. Below this, there are three main sections:

- Import Setting:** Contains a 'Path' field with a 'Choose File' button and the text 'No file chosen'. Below the field is an 'Import Setting' button.
- Export Settings:** Contains an 'Export Settings' button.
- Default Settings:** Contains a 'Keep' section with an unchecked checkbox for 'Image Configuration' and a 'Load Default' button below it.