




1 |




2 |




3 |




4 |




5 |




6 |






7 |





8 |




Do not position light sensor below edge of cover (IR only).



**FLEXIDOME IP 4000i | 5000i (IR) outdoor | FLEXIDOME IP starlight 5000i (IR) outdoor**  
 NDE-4502-A | NDE-4502-AL | NDE-5503-A | NDE-5503-AL | NDE-5502-A | NDE-5502-AL | NDE-4512-A | NDE-4512-AL



**Project Assistant App + Configuration Manager + Video Security Client**  
 Windows | iOS | android



**Bosch Security Systems B.V.**  
 Torenallee 49  
 5617 BA Eindhoven  
 Netherlands  
**www.boschsecurity.com**  
 © Bosch Security Systems B.V., 2022