




### Caution

- Before connecting the SVS-5E with DVR, ascertain the kind of the SATA cable. Two kinds of SATA cable are provided with SVS-5E product.




[Direct Cable]



[Cross Cable]

- 1) When connecting the SVR-3200/1680/1660/1645/960/945 model  
Use the direct cable and the cross cable together.



- 2) When connecting the SVR-1650E/1640E/950E model  
Use the direct cable only.

