


DA-WM2160 INSTALLATION MANUAL



This manual is intended for users of the DA-WM2160 wall mounting bracket. It includes instructions for mounting the DA-WM2160 wall mounting bracket to a wall.




- **This bracket is intended to be used with some models of dome cameras. Do not use it with other models of cameras.**
- **This installation should be performed by a qualified service personnel in conformance to all local codes.**
- **You may need to reinforce the wall. If the wall is not strong enough to support the camera, the camera may fall.**
- **Do not use this product for other purposes.**

Mounting


Mount the bracket to the wall as follows:

Mount bracket to the wall by using the anchors and screws.



Connect your camera to the bracket as follows:

Assemble the camera body to the bracket by tightening the screws.



- 1 TC-D4222RX / TC-D4221RXP Model: Screw No.1 (2-point)
- 2 TC-D4211RX Model: Screw No.2 (3-point)
- 3 DC-D3212RX-N / DC-D3212X-N / DC-D3214RX-N / DC-D3214X-N Models: Screw No.3 (2-point)
- 4 DC-D4213RX Model: Screw No.4 (2-point)
- 5 DC-D4223RX / DC-D4233RX / DC-D4212R Models: Screw No.5 (2-point)

Dimensions

Unit: mm

