



Installing an EyeSpy247 camera on a Mac

All our cameras are accessible on Windows, Mac and Linux computers. However, the software CD provided will only currently operate on Windows PCs for install purposes.

In any case, installing an EyeSpy247 camera on a Mac is really very easy. Your starting point is one of the two following options:

1) Connect up the camera to your router via an ethernet cable and power it up. Once that's done simply locate the camera on your network (use the Network function on your Mac to find the camera) and make a note of it's local IP address (e.g. 192.168.1.3 or similar).

Then simply paste this IP address into your web browser at which point you will be able to access the camera's web interface.

Or...

2) Alternatively, download and install the software from the following link on to your Mac PC or laptop: <http://mac.softpedia.com/get/Network-Admin/Network-Device-Finder.shtml>

Now, connect up your camera to your router, run the above software on your PC/laptop and it will locate the camera for you on your network and also give you the local IP address for it. Then just copy and paste this IP address into your web browser to access the camera's web interface.

Once you have access to the camera's web interface and have signed up for your free EyeSpy247 account on our website all you need to do is follow the remaining steps as per our install video at <http://www.youtube.com/user/eyespy247com> to complete the setup.

Www.eyespy247.com
Eyespy247 is a division of Defuturo Ltd
Copyright Defuturo Ltd 2010



www.use-ip.co.uk
01304 827609